



NOTES:

1. SERVICE TAPS SHALL BE USED AS SAMPLE TAPS WHERE POSSIBLE.
2. ALL MATERIAL SHALL BE APPROVED BY THE TOWN OF JUPITER WATER UTILITIES PRIOR TO INSTALLATION.
3. TAPPING SADDLES:
FOR D.I.P., USE 1" DOUBLE STRAP TAP SADDLE WITH AWWA THREADS.
FOR C-900 PVC, USE FORD S-90 SERIES TAP SADDLE WITH AWWA THREADS.

WATER MAIN SAMPLE POINT (IN-LINE)

JUPITER UTILITIES
CONSTRUCTION STANDARDS AND DETAILS

DATE APPROVED:
10/2013
DRAWING No. W-16